

Binding two JR/Spektrum receivers and programming fail-safe for PowerBox Royal and RRS Champion

This article will cover PB Royal set up with X9303, 10X (2.4) and 12X JR radios. Please follow below steps along with instructions covered in the PB manual:

1. You need to connect FS1 and FS2 to a spare proportional channel such as Gear on the receiver.
2. Set that channel (in this case the gear channel) to travel from 0 to +100. Default is otherwise, you need to make that change.
3. Now you will need to do a smart bind with the gear switch pointing to +100 not 0. To do this, plug your bind plug in the receivers, turn the receivers on, take the bind plugs out before you turn the TX on. Receivers will continue blinking. Now turn on your TX while holding the bind button and gear switch pointing to +100.
4. Once step 3 is done you need to put the gear switch back to point at 0 and go to your switch assignment menu and INH the gear channel.

Reza Gholamipour